

FLOAT VALVE USER MANUAL

PRODUCT INFORMATION

Valve Name	: FLOAT VALVE
Nominal Diameter (DN)	: DN40-DN150 / DN200-DN300
Material	: Cast Iron, Ductile Iron, Cast Steel, Stainless Steel, Bronze
Nominal Pressure (PN)	: 10 bar /16 bar
Working Temperature	: -10°C ... +80°C

APPLICATION AREAS

- Cold and hot water systems
- Drinking water and irrigation systems
- Firefighting systems
- Pumping stations
- Storage tanks
- Pipe lines

INSTALLATION AND OPERATION INSTRUCTIONS OF THE FLOAT VALVE

*Before mounting the valve, the pipeline should be cleaned with pressure air or steam in order to eliminate the potential burrs, corruptions, foreign substances and dirt which may exist within the line.

*Both the axes of the pipes where they will be mounted and the hole axes of the connection element to be used should be in the same axis.

*In flanged connections, bolts suitable for flange holes should be used.

*If the connection element is flange, its bolts will be released by tightening them mutually, then the bolts will be tightened back in torque values given mutually.

*If the space for valve is left during installation, both the length of the valve and the length of the leakage elements to be used should be calculated before leaving such space.

*If the type of the connection will be threaded, the length of the thread on the pipe should not be less than the length of the valve thread.

*For the valve to be newly mounted, the labels / covers on both flanges should be removed.

*The valve to be mounted on the installation should be mounted considering the flange side, where the technical specifications are indicated, will be the inlet part. Afterwards, the other side will be mounted on the installation so as to eliminate the possibility of pulling tension.

*While connecting the check valve to the installation, please ensure that the direction arrow should be in flow direction.

*For detail information, please look at the DIKKAN catalogue of product or get in touch with our company.

*Repairing and changing components cannot be done by end user. These shall be done by manufacturer